

Residual Current Circuit Breaker WiNtrip

IEC61008

CE



We touch your electricity everyday!

WiNtrip RCCB

From Bungalows to High Risers, from Trade Centres to Hotels, from Clinics to Hospitals, from elevators to escalators electricity is the foremost requirement. Electricity has become an integral part of our life so common to our daily requirements that we forget its intricacies and hazardous behaviour.

Day after day we come across many un to do events hampering human lives due to negligent usage of electricity. Even large number of Industrial and Domestic fire is attributed to and caused by electricity.

Faulty insulated equipments or wrong useage of electrical devices cause current to flow through insulation to the earth. This is leakage current. This current poses two severe risk factors which are:

Fire Risk

Electrocution Risk

Residual Current Circuit Breaker provides the function of isolation switching and earth leakage protection of electrical circuits. It also provides the indirect protection of the operator's body against the dangerous effects of electric current. It is also a protective device against fire caused by the electrical circuit fault.

Physiological Effect of Electric Current on Human Body

| 500 mA | - | Immediate cardiac arrest resulting in death | | |
|-----------|---------|--|--|--|
| 70-100 mA | | Cardiac fibrillation; the heart begins to vibrate and and no longer beats at a steady rate. This situation is dangerous since it is irreversible | | |
| 20-30 mA | (H) | Muscle contraction can cause respiratory paralysis | | |
| 10 mA | | Muscle contraction : the person remains "stuck" to the conductor | | |
| 1-10 mA | F | Prickling sensations | | |

As per Indian Electricity Rules 1956 at all installations with load above 5 KW use of RCCB is compulsory









Highlights

A state-of-the art product fit for Industrial, Residential and Commercial applications.

It is one piece residual current circuit breaker which is used both for control and isolation of electrical circuits. It provides total protection to all living beings against direct and indirect contact as well as to installations, big or small, against insulation faults. **Human life is valueless and WiNtrip RCCB is the solution provider for safeguarding it.**

Majority of mishaps occur due to current leakage consequently leading to fire. WiNtrip RCCB of the required rating instantly detects this leakage and terminates the supply reducing the risk of any kind of fire.

- Provides protection against earth fault/leakage current and also fulfill the function of isolation.
- Automatically measures and disconnect the circuit when earth fault/leakage current occurs and exceeds the rated sensitivity.
- High short-circuit current withstand capacity 10kA
- Dual termination possible for cable and comb type busbar connection
- Equipped with finger protected connection terminals (Ip20)
- Fire resistant plastic parts to withstand abnormal heating and strong impact
- Independent of power supply and line voltage. Also free from external voltage fluctuation.
- Incorporates a filtering device for prevention of nuisance tripping due to transient voltage
- High current rating up to 63A















Characteristics

| Standards | | EN/IEC 6108-1 | | |
|----------------------------|---|---------------------|----------------------|--|
| Residual tripping charac | cteristics | | AC | |
| Tripping time at I n | Instantaneous | ms | <40 | |
| | Selective | ms | >150 | |
| Rated current | | A | 25, 40, 63 | |
| Rated residual current I | n | mA | 30, 100, 300 | |
| Calibration temperature | 9 | °C | 30 | |
| Number of poles versus | modules | | 1 | |
| Rated voltage Un | 2PAC | V | 240 | |
| | 4PAC | V | 415 | |
| Frequency | | Hz | 50/60 | |
| Maximum service voltag | ge Ubmax | V | 2P=265/4P=455 | |
| Minimum service voltag | eUbmin | V | 2P=100/4P=190 | |
| Power supply | | | Top/Bottom | |
| Rated making and break | king capacity (Im) | A | 500 (or 10xln) | |
| Residual making and br | | A | 500 (or 10xln) | |
| Conditional short-circui | | A | 10000 fuse 100A gLgG | |
| Conditional residual sho | ort-circuit capacity (I c) | A | 10000 fuse 100A gLgG | |
| Grid distance (safety dis | stance between two devices) | mm | 35 | |
| Isolator application | | | yes | |
| Insulation degree | Insulation voltage | V(DC) | 440 | |
| | Shock voltage (1.2/50 s) | kV | 6 | |
| | Insulation resistance | m | 1000 | |
| | Dielectric strength | V | 2500 | |
| Shock resistance (in x, y | , z direction) (EN / IEC 60077/16.3) | 40g, 18 shocks 5 ms | | |
| Vibration resistance (in) | k, y, z direction; EN / IEC 60068-2-6) | 1.5g, 30 min, 080Hz | | |
| Endurance | electrical at Un, In | | 10000 | |
| | mechanical at Un, In | | 20000 | |
| Protection degree (outs | ide/inside electrical enclosure) with door | | IP20/IP40 | |
| Self extinguish degree (a | according to UI94) | | V2 | |
| Tropicalisation (acc. to | EN/IEC 60068-2, DIN 40046) | °C/RH | +55/95% | |
| Pollution degree (acc. E | N/IEC 60947-1) | | 3 | |
| Operating temperature | | | AC (-5+60) | |
| Storage temperature | | °C | -25+70 | |
| Terminals capacity | Rigid cable min/max (top) | mm ² | 1.5/35 | |
| | Flexible cable min*/max (top) | mm² | 1.5/25 | |
| | Rigid cable min/max (bottom) | mm ² | 1.5/35 | |
| | Flexible cable min*/max (bottom) | mm ² | 1.5/25 | |
| | (*Flexible cable 0.75/1/1.5 mm ² | with cable lug) | | |
| Busbars systems | Pin | | yes | |
| | Fork | | yes | |
| CEmarking | | | yes | |
| Torque | Top/Bottom | Nm | 5/5 | |
| | | | | |

 $\left[\wedge \right]$

Applications





Wiring Diagram







Terminal Connection

Performance

| Type Ao | | | |
|---|-----|---------------------|---|
| Thermal setting In | А | 25, 40, 63 | |
| Residual current l∆n | mA | 30, 100, 300 | |
| Rated voltage AC Un | V | 2P:240;4P:415 | |
| Minimum operating voltage U_{bmin} | V | 2P:100;4P:190 | |
| Mechanical/electrical endurance | | 20000/10000 | |
| Tropicalisation acc.to | | | |
| EN/IEC 60068-2-28/2-30 and DIN 40046 | | 95%RH at 55°C | |
| Terminal capacity Aexible/rigid cable | mm² | 25/35 | |
| Poles | | 2,4 | |
| Nuisance tripping resistance | | 250A 8/20us; | |
| | | 200A 0.5us - 100kHz | 2 |
| Ambient temperature | °C | -5 upto 40 | |
| Weight | g | 2P:220; 4P:385 | |
| | | | |

Short-circuit Capacity

| Acc. to EN/IEC 61008-1 | Im = 500A | |
|------------------------------|---------------------------------------|--|
| Making and breaking capacity | $I\Delta m \ge 500A$ from 16 upto 40A | |
| | $I\Delta m = 10In$ from 63 upto 100A | |
| Short-circuit capacity | Inc = 10000A at 240/415V | |
| | fuse 80A gG | |
| | | |

Normal operation and mounting requirement

- 1. Ambient temperature $-5^{\circ}C \sim +40^{\circ}C$ •Altitude above sea level less than 2000 m.
- 2. Humidity not exceeding 50% at 40°C and not exceeding 90% at 25°C.
- 3. Installation class II or III.
- 4. Pollution degree 3.
- 5. All equipments used should be properly earthed.
- For right operation should ensure that the neutral conductor on the load side of the RCCB must not be linked to earth. Otherwise tripping may be impaired or nuisance tripping may occur.
- 7. Installation method DIN Rail mounting type.
- 8. Product should be installed vertically at the place where there shall be no severe impact and vibration.
- 9. The product is switched on when the handle is at upper position.

RCCB Tripping Cause Detection & Remedy

- 1. Switch OFF all the MCBs connected to the circuit downstream the RCCB.
- 2. Switch ON the RCCB and switch ON the MCBs one by one.
- 3. During switching ON of a particular circuit RCCB keeps tripping frequently.
- 4. In this circuit the fault persists.
- 5. Isolate the faulty circuit, correct the fault. Now the RCCB will not trip.


Technical Data

WiNtrip

Working Principle


TheR CCBw orkso nt hec urrentb alancep rinciple.T hes upply conductors are passed through a torroid and form the primary windings of a current transformer. Its secondary winding is connected to a highly sensitive electromagnetic trip relay, which operates the trip mechanism.

In a healthy circuit, sum of the current in phases, is equal to the current in the neutral and the vector sum of all current is equal to zero. If there is any insulation fault in the current and leakage current fows to earth, the current do not balance and their vector sum is not equal to zero. This imbalance is detected by the core balanced current transformer, the RCCB is tripped and supply to load is interrupted.



Sensitivity Selection Criteria


| Sensitivity | Application |
|-------------|--|
| 30mA | Designed for additional protection against direct contact. The 30 mA RCCB protects against leakage currents and indirect contact with earth loop impedance up to 1667 Ohms. |
| 100mA | Is suitable for protection against indirect contact and leakage current for larger installations. The 100 mA RCCB's operate within 30 ms, but do not provide the same level of personal protection as the 30 mA units. The 100 mA RCCB protects against leakage currents and indirect contact with earth loop impedance up to 500 ohms. |
| 300mA | A less sensitive protection device suitable for large installations having high levels of leakage current. 300 mA RCCB's protect against leakage current and indirect contact up to 167 ohms earth loop impedance. |



Selection

| Description | | Rated Current | Sensitivity | Reference |
|-------------|-------------|------------------|------------------------|---|
| Double Pole | | 25 | 30mA 100mA 300mA | CSRB2P25A30 CSRB2P25A100 CSRB2P25A300 |
| | | 40 | 30mA 100mA 300mA | CSRB2P40A30 CSRB2P40A100 CSRB2P40A300 |
| | | 63 | 30mA 100mA 300mA | CSRB2P63A30 CSRB2P63A100 CSRB2P63A300 |
| | | 25 | 30mA 100mA 300mA | CSRB4P25A30 CSRB4P25A100 CSRB4P25A300 |
| Four Pole | | 40 | 30mA 100mA 300mA | CSRB4P40A30 CSRB4P40A100 CSRB4P40A300 |
| | 21 41 01 NI | 63 | 30mA 100mA 300mA | CSRB4P63A30 CSRB4P63A100 CSRB4P63A300 |

Dimensional Drawing





www.cselectric.co.in

C&S Electric Ltd. (LV Components Division)

Corporate Office : 222, Okhla Industrial Estate, New Delhi - 110 020 India Tel. : +91-11-3088 7520 - 29, Fax: +91-11-2684 7154, 2682 9063

Central Marketing Office: 222, Okhla Industrial Estate, New Delhi - 110 020 India Tel.: +91-11-3088 7520-29, Fax: +91-11-2684 8241, 2684 7342 email: cmo@controlsindia.com, info@controlsindia.com

International Business Division: 222, Okhla Industrial Estate, New Delhi - 110 020 India Tel. : +91-11-4161 3503, 3088 7520-29, Fax: +91-11-2683 8291, 2684 7342 email : exports@controlsindia.com

